




RGB DIMMER & REMOTE TUTORIAL

The dimmer and remote lets you experience all the amazing features your RGB Custom Neon® sign has to offer.

The dimmer is the little black box that comes with your sign, and you use the remote to control it. In the diagram, you see the dimmer connecting to the sign and the adapter, which then plugs into the wall. You will need 3 AAA batteries.



This button is used to turn your sign on and off.

Use the color wheel with static mode to set your sign to one specific color.

When in static mode, these buttons allow you to increase and decrease the brightness of your sign.

When in dynamic mode, these buttons allow you to change the speed of the flashing, flickering and pulsing.



This button allows you to 'pause' the sign on a specific color in a dynamic mode.

This button is used to switch between the dynamic modes. These modes offer a range of flashing, flickering and pulsing options.

IMPORTANT:
The remote will work up to 65ft in range of your dimmer. Make sure the dimmer is in clear range of the remote.